




















THE SNOWY CASTLE


ASSEMBLY INSTRUCTIONS



-  78
-  262
-  12
-  34



CASTLE KIT







-  48
-  217
-  2
-  3
-  18
-  9
-  2
-  2
-  2
-  12
-  24
-  2
-  2

























14




15




16




17



18



19



20